






01 118 00 06<sup>L</sup>

**R87..**



**R87F..**



(→ 131)	DR71M	DR80S	DR80M	DR90M	DR90L	DR100M	DR100L/LC	DR132S	DR132M/MC	DR160..	DR180S/M	DR180L/LC
AC	139	156	156	179	179	197	197	221	221	270	316	316
AD	119	128	128	140	140	157	157	170	170	228	253	253
ADS	129	139	139	150	150	158	158	172	172	228	253	253
L	581	590	621	623	643	673	703	746	796	837	906	966
LS	649	671	702	716	736	766	796	858	908	974	1095	1155
LB	209	218	249	251	271	301	331	374	424	465	534	594
LBS	277	299	330	344	364	394	424	486	536	602	723	783